



OMEGA4K / UHD 3x2 Matrix Switcher for HDMI and USB-C with HDMI Outputs

Application Programming Interface

Version Information

Version	Release Date	Notes
1	Dec 2018	Release
2	Aug 2019	Added System sta and TrigCEC commands
3	Dec 2019	Removed System sta and TrigCEC commands Added IP802.1x RepCmdTime, and RepeatCmd

Commands

The following tables provide an alphabetical list of commands available on the AT-OME-SW32.

Commands can be sent using RS-232 or Telnet.

There should be a 0.5 second delay between each command sent to the unit.

Default port for Telnet is 23.

Each command is case sensitive, do not change: capitalization, spacing, or lettering.

Each command is terminated with a carriage return.

If the command fails or is incorrect the feedback should be "Command FAILED:" followed by the sent command.



IMPORTANT: Each command is terminated with a carriage-return (0x0d) and the feedback is terminated with a carriage-return and line-feed (0x0a).

Command	Description
Blink	Enable/Disable blinking of the front panel POWER LED
CommaWait	Enable/Disable a comma adding a 5 second delay between commands
DispBtn	Sets the command triggered through display control (set in the webGUI)
InputStatus	Displays the status for each input
IP802.1x	Sets the 802.1x security status
IPCFG	Displays IP address configuration
IPDHCP	Turns DHCP on / off
IPStatic	Sets a static IP address
Lock	Locks the buttons on the front panel
LRAUD	Turns on/off analog audio output
Mreset	Sets the unit back to default settings
PWOFF	Execute this command to power-off the unit
PWON	Execute this command to power-on the unit
PWSTA	Displays the power state of the unit
RepCmdTime	Sets how many times a display command is repeated when repeat is enabled
RepeatCmd	Enables/disables display command repeat
RS232zone	Displays the routing state of the unit
Status	Displays the routing state of the unit
Type	Displays the model of the unit
Unlock	Unlocks the buttons on the front panel
Version	Displays the current firmware version of the unit
VOUtmute	Mutes/Unmutes audio output volume
x?\$	Mutes/Unmutes AV signals for the specified output channel
x?AVx&	Switch a specific input to a specific output

Blink

Enable/Disable blinking of the front panel POWER LED.

Syntax

Blink **X**

Parameter	Description	Range
X	Value	on, off, sta

Example

Blink on

Feedback

Blink on

CommaWait

Enable/Disable a comma adding a 5 second delay between commands. Default is on.

Syntax

CommaWait **X**

Parameter	Description	Range
X	Value	on, off, sta

Example

CommaWait on

Feedback

CommaWait on

DispBtn

Sets the command triggered through display control (set in the webGUI).

Syntax

DispBtn **X**

Parameter	Description	Range
X	Setting	on, off, tog, mute, vol+, vol-, sta

Example

DispBtn on

Feedback

DispBtn on

InputStatus

Displays the status for each input.

Syntax

InputStatus

Examples

InputStatus

Feedback

InputStatus 011



NOTE: The feedback will display channel status: 0 is no signal detected and 1 is signal detected.

IP802.1x

Sets the 802.1x security status.

Syntax

IP802.1x ?

Parameter	Description	Range
?	Value	disable, PEAP, TTLS, TLS, sta

Example

IP802.1x sta

Feedback

IP802.1x TTLS

IPCFG

Displays the current network settings for the unit.

Syntax

IPCFG

Example

IPCFG

Feedback

IP Addr 192.168.11.196
Netmask 255.255.255.0
Gateway 192.168.11.254
IP Port 23

IPDHCP

Turns DHCP on / off. Default is on.

Syntax

IPDHCP X

Parameter	Description	Range
X	Value	on, off, sta

Example

IPDHCP on

Feedback

IPDHCP on

IPStatic

Sets a static IP address.

Syntax

IPStatic **X Y Z**

Parameter	Description	Range
X	IP address	0 to 255 (per byte)
Y	Subnet mask	0 to 255 (per byte)
Z	Gateway (router)	0 to 255 (per byte)

Example

IPStatic 192.168.1.112 255.255.255.0 192.168.1.1

Feedback

IPStatic 192.168.1.112 255.255.255.0 192.168.1.1

Lock

Locks the front panel of the matrix so no buttons are active.

Syntax

Lock

Example

Lock

Feedback

Lock

LRAUD

Turns on/off analog audio output. Default is on.

Syntax

LRAUD **X**

Parameter	Description	Range
X	Value	on, off, sta

Example

LRAUD sta

Feedback

LRAUD on

Mreset

Sets matrix back to the default settings.

Syntax

MReset

Example

Mreset

Feedback

Mreset

PWOFF

Turns the unit off. Front panel LED will illuminate red when off.

Syntax

PWOFF

Example

PWOFF

Feedback

PWOFF

PWON

Turns the unit on. Front panel LED will illuminate blue when on.

Syntax

PWON

Example

PWON

Feedback

PWON

PWSTA

Displays the power status of the matrix.

Syntax

PWSTA

Example

PWSTA

Feedback

PWON

RepCmdTime

Sets how many times a display command is repeated when repeat is enabled.

Syntax

RepeatCmd **X**

Parameter	Description	Range
X	Amount	2 - 4, sta

Example

RepeatCmd sta
RepeatCmd 3

Feedback

RepeatCmd 2
RepeatCmd 3

RepeatCmd

Enables (on) / disables (off) display command repeat.

Syntax

RepeatCmd **X**

Parameter	Description	Range
X	State	on, off, sta

Example

RepeatCmd sta

Feedback

RepeatCmd on

RS232zone

Use to trigger the SW32's RS-232 port to send the specified command to the display.

Syntax

RS232zone[X]

Parameter	Description	Range
X	Command	String

Example

RS232zone[VOL23]

Feedback

RS232zone[VOL23]

Status

Displays the current route status.

Syntax

Status **X**

Example

Status

Feedback

x3Vx1, x1Vx2

Type

Brings up the model information.

Syntax

Type

Example

Type

Feedback

AT-OME-SW32

Unlock

Unlocks the front panel of the matrix, enabling the buttons again.

Syntax
Unlock

Example

Unlock

Feedback

Unlock

Version

Brings up the current firmware version.

Syntax
Version

Example

Version

Feedback

1.0.00

VOU TMute

Mutes/unmutes the output audio channels.

Syntax
VOU TMuteX Y

Parameter	Description	Range
X	Channel	1 - 2
Y	Value	on, off, sta

Example

VOU TMute1 sta

Feedback

VOU TMute1 on

x?\$

Mutes/Unmutes AV signals for the specified output channel.

Syntax
x?\$ Y

Parameter	Description	Range
X	Output	1 - 2
Y	Variable	on, off, sta

Example

x2\$ sta

Feedback

x2\$ on

x?AVx&

Switch audio and video input to output.

Syntax

x?AVx&

Parameter	Description	Range
?	Input	1 - 3
&	Output	1 - 2

Example

x1AVx3

Feedback

x1AVx3

